

Tab HW

On the HW tab, use the buttons to navigate through the TOPODRONE P24 menu. This requires an HDMI connection to an external monitor. Use HW tab only for specific custom settings.

ON

Service

ON

OFF

ON

PWR

ON

OFF

ON

USB

ON

OFF

Control

LEFT

RIGHT

UP

DOWN

CENTER

MENU

FN

Revision #3
Created 30 October 2024 14:32:41 by Support 1
Updated 11 November 2024 15:31:14 by Support 1