


# AQUAMAPPER

Select the "AQUAMAPPER" tab to configure the processing parameters of AQUAMAPPER modules.



If necessary, adjust the Roll and Pitch angles. Closer to zero values of these angles will help to increase the share of vertical measurements in the processing process.

The optimal angle values are in the range from -8 to +8 degrees.

Revision #1

Created 19 November 2024 08:08:47 by TOPODRONE SUPPORT

Updated 19 November 2024 08:09:52 by TOPODRONE SUPPORT